

DIRECTIONS FOR ATTACHING THE BENNETT ALL STEEL NET TO BASKETS.

Place U hook on top of hoop as in blue print #1, snap U hook down on to hoop as in print #2, repeat until you have 12 U hooks on hoop about $4\frac{3}{4}$ inches apart. Now cut the cord which ties the top of net together and open up net, then start at right side of back brace and with all of net facing you start hanging net by slipping ring up and hang on one side of U hook continue clockwise until you have the 12 rings on the 12 U hooks. Now inspect to see that net hangs freely all around and evenly spaced. Next starting anywhere slip ring up on U hook about $\frac{1}{2}$ " and with fingers close U hook to position #3 and let ring drop down to position at bottom of U hook, continue until you have the 12 done likewise, now with a pair of pliers close all the small loops on bottom of U hooks and the net will be ready for use, and U hooks will look like spare which I have tagged and labeled spare sample.

On hoops which have the solid horizontal back brace the best method to attach centre U hook rear is to drill a $\frac{3}{8}$ " hole thru plate just behind hoop and pass one side of the U hook down and complete as before.

Caution, have all the link joints on outside of net instead of on the inside. Now play basket ball.

Joseph H. Bennett

20 Richards Street,

Worcester, Mass.